

LISTA DE REFACCION

MODELO DS5000

Pos.	NUMERO	DESCRIPCION	Cant.	NOTA
001	265128-3	HEX.SOCKET C.S HEADSCREW M6X33	1	
002	763172-9	DRILL CHUCK S16	1	
003	325494-1	SPINDLE	1	
004	254211-1	KEY 5	1	
005	285807-7	BEARING RETAINER 22-36	1	
006	211206-7	BALL BEARING 6202LLB	1	
007	266211-9	TAPPING SCREW 5X40	4	
008	140620-9	GEAR HOUSING COMPLETE	1	
009	211016-2	BALL BEARING 626LLB	1	
010	226028-2	GEAR COMPLETE 7-41	1	
011	261008-1	FIBER WASHER 6	1	
012	257018-4	RING 15	1	
013	221261-1	SPUR GEAR 47	1	
014	961054-1	RETAINING RING S-14	1	
015	256180-2	PIN 3	1	
016	452066-0	GASKET	1	
017	140619-4	GEAR HOUSING COVER COMPLETE	1	
018	211031-6	BALL BEARING 608LLB	1	
019	241850-6	FAN 60	1	
020	513808-8	ARMATURE ASS'Y 220V INC. 18,19,21,22	1	
021	681659-8	INSULATION WASHER	1	
022	211031-6	BALL BEARING 608LLB	1	
023	452063-6	BAFFLE PLATE	1	
024	520074-0	FIELD ASS'Y 220V	1	
025	266095-5	TAPPING SCREW 5X55	2	
026	643550-8	BRUSH HOLDER CAP 5-8	2	
027	195010-1	CARBON BRUSH CB-411	1	
028	868458-7	DS5000 NAME PLATE	1	
029	232260-8	LEAF SPRING	2	
030	265995-6	TAPPING SCREW 4X18	4	
031	188921-7	HANDLE SET INC. 32	1	
032	188921-7	HANDLE SET INC. 31	1	
033	140618-6	MOTOR HOUSING COMPLETE	1	
034	265995-6	TAPPING SCREW 4X18	3	
035	188920-9	SWITCH HANDLE COVER SET INC. 47	1	
036	682559-5	CORD GUARD 8	1	
037	666015-3	POWER SUPPLY CORD 1.0-2-2.5	1	
039	265995-6	TAPPING SCREW 4X18	2	
040	687063-9	CORD CLAMP	1	
043	651564-3	SWITCH SL220SD-4	1	
044	421297-2	DUST COVER	1	
046	911233-1	PAN HEAD SCREW M5X20	4	
047	188920-9	SWITCH HANDLE COVER SET INC. 35	1	
A01	152492-0	GRIP 36 COMPLETE	1	
A02	763443-4	CHUCK KEY S16	1	

DIAGRAMA

MODELO: DS5000

